

Americas

BorgWarner (World Headquarters)
3800 Automation Avenue
Auburn Hills, MI 48326/USA

BorgWarner Turbo Systems
P.O. Box 15075
Asheville, NC 28813/USA

BorgWarner Brasil Ltda.
Estrada da Rhodia Km 15
P.O. Box 6540
13084-970 Campinas-SP/Brasil

Europe

BorgWarner Turbo Systems GmbH
Mannheimer StraBe 85/87
67292 Kirchheimbolanden/Germany

BorgWarner France SAS
23 bis, avenue de l'Europe
78400 Chatou/Frankreich

BorgWarner Turbo Systems Kft.
Tancsics Mihaly ut 111.
H-2840 Oroszlany/Ungarn

Asia

BorgWarner Turbo Systems
Shin-Yokohama Turbo Branch
Sumitomo Fudosan
Shin-Yokoyama, Kouhoku-ku
Yokohama-shi, Kanagawa 222-0033

BorgWarner Automotive Components (Ningbo) Co., Ltd.
Turbo & Emissions Systems
No.188, Jingu Zhong Rd. (West)
Yinzhou District
Ningbo P.R. China 315104

SeohanWarner Turbo Systems Ltd.
Eoyeon-Hansan Industrial Park
893-1, Eoyeon-ri, Cheongbuk-myeon
Pyongtaek-shi, Kyonggi-do
451-833 Korea



EFR Turbocharger



Quick Reference Guide



www.borgwarnerboosted.com



EFR Super-Core Product Selection Guide	
Rotors	Super-Core
6255	179139
6258	179140
6758	179375
7064	179354
7670	179350
8374	179257
9180	179356

Each Super-Core includes a fully assembled bearing and rotor system along with a complete compressor stage. This includes the compressor stage accessories such as the CRV and BCSV assembled to the comp cover.

Not included is the turbine housing assembly, turbine housing clamp plate hardware, or wastegate parts.

To build a complete turbo from scratch, the Super-Core must be mated with with a turbine housing, wastegate bracket kit, wastegate canister, and hardware/installation kit.

Accessory Kits	
179430	Speed Sensor Kit
179423	Hardware/Installation Kit
179424	Compressor Recirculation Valve Kit
179425	Boost Control Solenoid Valve Kit
179426	Wastegate Hose Kit

EFR Wastegate Canister Selection Guide			
Core Assy	0.64 a/r TH	0.83 a/r TH	0.92 a/r TH
6255	179282, 179283, or 179284	N/A	N/A
6258	179282, 179283, or 179284	N/A	179420, 179421, or 179422
6758	179282, 179283, or 179284	N/A	179420, 179421, or 179422
7064	N/A	179285, 179286, or 179287	179285, 179286, or 179287
7670	N/A	179285, 179286, or 179287	179285, 179286, or 179287
8374	N/A	179285, 179286, or 179287	179285, 179286, or 179287
9180	N/A	179285, 179286, or 179287	179285, 179286, or 179287

EFR Wastegate Canister Bracket Kit Selection Guide			
Core Assy	0.64 a/r TH	0.83 a/r TH	0.92 a/r TH
6255	179427	N/A	N/A
6258	179427	N/A	179428
6758	179427	N/A	179428
7064	N/A	179428	179428
7670	N/A	179428	179428
8374	N/A	179429	179429
9180	N/A	179429	179429

EFR Turbo Assembly Product Selection Guide	
179149	EFR-6255 Turbo Assembly, 0.64a/r WG Single Scroll
179150	EFR-6258 Turbo Assembly, 0.64a/r WG Single Scroll
179359	EFR-6258 Turbo Assembly, 0.92a/r WG Twin Scroll
179388	EFR-6758 Turbo Assembly, 0.64a/r WG Single Scroll
179374	EFR-6758 Turbo Assembly, 0.92a/r WG Twin Scroll
179355	EFR-7064 Turbo Assembly, 0.83a/r WG Single Scroll
179389	EFR-7064 Turbo Assembly, 0.92a/r WG Twin Scroll
179391	EFR-7064 Turbo Assembly, 1.05a/r non-WG Twin Scroll
179351	EFR-7670 Turbo Assembly, 0.83a/r WG Single Scroll
179390	EFR-7670 Turbo Assembly, 0.92a/r WG Twin Scroll
179392	EFR-7670 Turbo Assembly, 1.05a/r non-WG Twin Scroll
179258	EFR-8374 Turbo Assembly, 0.83a/r WG Single Scroll
179357	EFR-8374 Turbo Assembly, 0.92a/r WG Twin Scroll
179393	EFR-8374 Turbo Assembly, 1.05a/r non-WG Twin Scroll
179358	EFR-9180 Turbo Assembly, 0.83a/r WG Single Scroll
179394	EFR-9180 Turbo Assembly, 1.05a/r non-WG Twin Scroll

Each turbo assembly comes assembled with wastegate canister (on WG models), oil inlet fitting, compressor recirculation valve, and boost control solenoid valve.

Not included with turbo assemblies:

1. Speed sensor
2. Turbine outlet v-band clamp
3. Turbine inlet gasket
4. Oil drain gasket or oil drain port fitting



Turbo Quick Reference Guide

